



2185 5<sup>th</sup> Avenue Ronkonkoma, NY 11779 Phone# (631)738-0324 Fax# (631)738-0325

## **Instructions for Conversion Kit**

- 1. Remove screws on outside of hatch. The rest of the work will be done from the inside.**
- 2. Install the L channels first. If needed cut to size, then screw into curb approximately 1/2" from the top.**
- 3. Install J channel next. Cut to size if needed. Screw to opposite end of operator.**
- 4. Install H channel last, this will be installed on same end as operator.**
- 5. Secure operator with 4 screws provided in the precut hole in the H channel.**
- 6. Center sash bracket on underside of frame and install with screws.**
- 7. Crank open operator and insert sash pin through top of chain and sash bracket.**
- 8. Insert spring side of insect screen into H channel(side with operator). Compress the springs and release opposite end into J channel.**
- 9. Enjoy your new vented skylight.**