



2185 5<sup>th</sup> Avenue Ronkonkoma, NY 11779 Phone# (631)738-0324 Fax# (631)738-0325

## **Instructions for Conversion Kit**

- 1. Remove screws on outside of Top. Apply Silicone to holes in flashing. The rest of the work will be done from the inside.**
- 2. Install the L-channels on each side of curb first. If needed cut to size, then screw into curb approximately 1/2" down from the top edge of curb.**
- 3. Install J-channel next. Cut to size if needed and push up to rest against underside of L-channel on the opposite end of operator.**
- 4. Install H-channel last, this will be installed on same end as operator. Cut to size if needed and push up to rest against underside of L-channel**
- 5. Insert C-clip over chain collar of operator before sliding operator into precut notch in H-channel**
- 6. Secure operator with 5 screws provided.**
- 7. Center sash bracket above chain on underside of frame and install with screws.**
- 8. Crank open operator and insert sash pin through top of chain and sash bracket.**
- 9. Insert spring side of insect screen into H channel(side with operator). Compress the springs and release opposite end into J channel.**
- 10. Enjoy your new vented skylight.**