



2185 5th Avenue Ronkonkoma, NY 11779 Phone#(631)738-0324 Fax# (631)738-0325

Installation Instructions Vented Curb Mounted Skylights

Vented curb mounted skylights are the perfect option for retrofit skylights on existing curbs or new site-built curbs. These skylights can be installed on flat and pitched roofs with a curb thickness able to support aluminum flashing and PVC curbliner. They can be installed on curbs without a pitch but when possible a $\frac{1}{2}$ " / FT pitch is recommended.

- 1. Prepare the curb to ensure that it is clear from any debris or residue.**
- 2. Apply a generous bead of sealant around the entire perimeter of the curb.**
- 3. Set skylight on curb and apply pressure to seat the skylight into the sealant.**
- 4. Attach skylight to curb on all 4 sides with #10 stainless steel screw. Screw spacing 12" O.C. and 4" min. from all corners.**